




CONSTRUCTION DETAIL DRAWINGS

Fox Blocks ICF Wall Systems



WALL SECTION

1. ESTABLISH TOP OF JOIST ELEVATION AND MARK THE FORM WITH A CHALK LINE.
2. ESTABLISH BOTTOM OF JOIST ELEVATION AND MARK THE FORM WITH A CHALK LINE.
3. 6.5 INCH WIDE BEVELED CUT-OUTS ARE TO BE PROVIDED IN THE FORM WALL. THE HEIGHT OF THE CUT-OUTS ARE DETERMINED AS SHOWN IN THE DRAWING ABOVE. (ONE INCH BELOW THE TOP CHALK LINE AND ONE INCH ABOVE THE BOTTOM CHALK LINE.
4. SCREW THE RIM JOIST TO THE FORM WEB STRIPS AT THE PROPER ELEVATION, LABELED "FOX BLOCKS".
5. LAYOUT AND INSTALL THE RIM JOIST ANCHOR BOLTS AS REQUIRED.
6. FILL THE FORMS WITH CONCRETE AND ALLOW THE CONCRETE TO CURE BEFORE INSTALLING JOIST HANGERS OR LOADING THE RIM JOIST.



This drawing is only to be used as a reference. The user shall check to ensure the drawing meets local building codes and construction practices by consulting local building professionals and officials. Changes to the drawing may be made by Fox Blocks without notice and assumes no liability in connection with the use of this drawing including modifications, copying or distribution.

Title:

RIM JOIST INSTALLATION

Date:

07/12/06

Drawing:

FOX-602